




1.6.2007

T151eh, T151eLS, T161c, T161h,
T161LS, T171c, T171h, T171LS,
T191h, T191LS





1.6.2007
 T151eh, T151eLS, T161c, T161h,
 T161LS, T171c, T171h, T171LS,
 T191h, T191LS



JARRUVENTTIILI
(LISÄVARUSTE)

BROMSSVENTIL
(EXTRA
UTRUSTNING)

BRAKE VALVE
(OPTIONAL
EQUIPMENT)


BREMSVENTIL
(EXTRAZUBEHÖR)

VALVE DE FREIN
(EQUIPEMENT
OPTIONNEL)

59-01

1.6.2007


T121c, T121h, T131c, T131h,
T151eh, T151eLS, T161c, T161h,
T161LS, T171c, T171h, T171LS,
T191h, T191LS



JARRUKIILA
(LISÄVARUSTE)BROMSSKIL (EXTRA
UTRUSTNING)BRAKE KEY
(OPTIONAL
EQUIPMENT)BREMSKEIL
(EXTRAZUBEHÖR)CLE DE FREIN
(EQUIPEMENT
OPTIONNEL)

59-05

1.6.2007

T121c, T121h, T131c, T131h,
T151eh, T151eLS, T161c, T161h,
T161LS, T171c, T171h, T171LS,
T191h, T191LS

PAINELMAJARRUT
(LISÄVARUSTE)

TRYCKLUFTSBROMS
(EXTRA
UTRUSTNING)

AIR PRESSURE
BRAKE (OPTIONAL
EQUIPMENT)


LUFTDRUCK
BREMSE
(EXTRAZUBEHÖR)

FREIN A PRESSION
D'AIR (EQUIPEMENT
OPTIONNEL)

59-07

1.6.2007

T121c, T121h, T131c, T131h,
T151eh, T151eLS, T161c, T161h,
T161LS, T171c, T171h, T171LS,
T191h, T191LS



PAINELMAJARRUT,
DUO-MATIC
(LISÄVARUSTE)

TRYCKLUFTSBROMS,
DUO-MATIC (EXTRA
UTRUSTNING)

AIR PRESSURE
BRAKE, DUO-MATIC
(OPTIONAL
EQUIPMENT)


LUFTDRUCK
BREMSE, DUO-MATIC
(EXTRAZUBEHÖR)

FREIN A PRESSION
D'AIR (EQUIPEMENT
OPTIONNEL)

59-11

1.6.2007

T121c, T121h, T131c, T131h,
T151eh, T151eLS, T161c, T161h,
T161LS, T171c, T171h, T171LS,
T191h, T191LS



HÄTÄJARRU
(LISÄVARUSTE)

NÖDBROMS (EXTRA
UTRUSTNING)

EMERGENCY BRAKE
(OPTIONAL
EQUIPMENT)

NOTBREMSE
(EXTRAZUBEHÖR)

FREIN DE SECOURS
(EQUIPEMENT
OPTIONNEL)

59-15

1.6.2007

T121c, T121h, T131c, T131h,
T151eh, T151eLS, T161c, T161h,
T161LS, T171c, T171h, T171LS,
T191h, T191LS

18

ACHTUNG! Für eine Notbremsung muss der Handbremshebel links unten am Kabinenboden verwendet werden. Nicht als Parkbremse geeignet.

344 213 00

19

CAUTION! If the brakes fail while driving, braking under control can be achieved by pulling the emergency brake lever up on the left side of the cab. Can not be used as parking brake.

344 691 00

